


Tone 2



When the button is pressed the tone sweeps up and down three times.

The lowest frequency is 50hz and the highest frequency is 1500hz.

The "while" loops change the frequency each time through.

