



ONE Waiting

TWO

FIVE

SIX

Waiting

Waiting SEVEN Waiting

EIGHT Waiting

NINE

Waiting

Waiting
THREE
Waiting
FOUR
Waiting

					1	1	
	seg						
	Α	В	С	D	E	F	G
ZERO	1	1	1	1	1	1	0
ONE	0	1	1	0	0	0	0
TWO	1	1	0	1	1	0	1
THREE	1	1	1	1	0	0	1
FOUR	0	1	1	0	0	1	1
FIVE	1	0	1	1	0	1	1
SIX	1?	0	1	1	1	1	1
SEVEN	1	1	1	0	0	0?	0
EIGHT	1	1	1	1	1	1	1
NINE	1	1	1	1?	0	1	1

All the subroutines for the individual numerals are the same as 7 Segment 1.



This "subroutine" waits for half a second for you to get your finger off the button, then checks the button every 1/100th second until the button goes "HIGH" before it moves on to the next instruction.

